

1801



PRECI-VERTIX STANDARD:

- 6 males with attached paralleling mandrel
- 6 yellow females
- 1 insertion tool

1811



PRECI-VERTIX P:

- 6 angled males for the best abutment and tissue contours
- 6 yellow females
- 1 insertion tool
- 1 paralleling mandrel


1812



PRECI-VERTIX P COMBI:

- 2 angled males for the best abutment and tissue contours
- 2 + 2 + 2 females
- 2 plastic castable housings
- 1 insertion tool
- 1 paralleling mandrel

REPLACEMENT PARTS



Strong friction:

- # 1806 6 red females
- # 1806B 50 red females

Normal friction:

- # 1802 6 yellow females
- # 1802B 50 yellow females

Reduced friction:

- # 1805 6 white females
- # 1805B 50 white females

PRECI-VERTIX HOUSING



- # 1808 6 castable housings
- # 1808B 50 castable housings

WWW.CEKA-PRECI-LINE.COM

SWISS MADE



CEKA REVAX

CEKA SOL

PRECI-HORIX

PRECI-VERTIX

PRECI-VERTIX AT

PRECI-BAR

PRECI-BALL

PRECI-CLIP

PRECI-CLIX EXTRACORONAL

PRECI-CLIX AXIAL

PRECI-CLIX RADICULAR

PRECI-TUBIX/MORTIX

PRECI-POST

PERMA-RET

3C-BOND

EXPANDO

PRECI-VERTIX®

PRECI-VERTIX®

CEKA
ATTACHMENTS
PRECI-LINE

Prospectus no 262.E-ed.B
Copyright© ALPHADENT NV 2/2008
BTW BE 0414.789.321 RPR Kortrijk

ALPHADENT NV
Textielstraat 24
8790 Waregem, Belgium
tel +32 56 629 100
fax +32 56 629 101


e-mail: info@ceka-preciline.com

Division of **ORSEUS**
D E N T A L



PRECI-VERTIX

- Easy procedures and servicing
- Esthetic: may be used with anterior abutments
- Minimal servicing
- Use with any dental alloy
- Inexpensive
- Excellent patient comfort
- Over 30 years of clinical use



PRECI-VERTIX offers long-lasting retention, unsurpassed lateral stability and minimal replacement. The elastic clips are easily replaceable and available in 3 friction levels.




Parallel the male patterns into the abutments. The male may be reduced to 3 mm vertical height if necessary. A shoulder for a lingual bracing arm is recommended. Cast and finish. Place the yellow clip over the male and block out all undercuts for duplication.



Make a refractory model and wax up the frame. Cover the reproduced attachment with wax. Invest and cast. Finish the prosthesis. Do not polish the inside of the metal sleeve. Leave it sandblasted. Reduce the occlusal of the male by 0.2 mm to relieve the attachment from occlusal loads. Press the clip with the insertion tool into the sleeve. To remove, use a pointed instrument. Engage and pull out the female.

OPTION FOR USING THE PRECI-VERTIX HOUSING RECOMMENDED

A burn-out plastic housing ensures a proper fit for the clip and provides excellent esthetics.



Assemble the housing with the white clip (# 1805). Adapt the housing to proper vertical height and gingival contour. A lingual arm is added directly to the housing. Shape the housing for porcelain or acrylic veneering and great esthetics. Sprue and remove the white female from the housing with a pointed instrument. Invest and cast. Apply veneering. Connect the extension of the housing to the cast framework with acrylic or composite.